

PROPER PACKING OF THE SAMPLES

1. Place the Fuel/Lube/Water sample (s) and document in the zip lock bag provided in the sampling kit into Maritec Naias IATA box.
This is to avoid leakage of sample to other shipments.
2. Place the IATA box(s) in the Express Flyer provided and secure/seal them tightly to the shape of the box. Refer below picture.
3. Print the Waybill, Commercial Invoice and MSDS from the sample pick up platform for DHL/FedEx/UPS collection.
4. If there is no IATA boxes available, please use a small carton boxes that fit the samples tightly.

Below are the example of a leak proof packing:

1. A leak-proof primary receptacle (s), filled up to 98% and sealed
2. A leak-proof secondary packing with absorbent material
3. A strong-rigid outer packing



Should you require further assistance, we can be reached at admin@maritec.com.sg. Thank you!