Maritec-Naias Sample
Pick Up
User Guide








Sampling & Logistic Procedure











Sample Collection

Collect approximately 5 litres of sample in a clean cubitainer.

Fill Each Bottle Partially in Turn

Cap the cubitainer and shake the contents vigorously for about 10 minutes to mix sample thoroughly. Fill each bottle one quarter at a time.

Bottle Labels, Sealing and Sample Distribution

- 1. Fill up all the labels and stick them on to the bottles.
- 2. The supplier and surveyors (if engaged for the job) should witness the sealing of the bottles. Record the Seal number on the CE Report Form and BDN.
- Distribute the 4 sample bottles as follows:
- a. Retain on vessel
- b. Retain on Vessel for MARPOL Annex VI
- c. Send to Maritec-Naias Laboratory
- d. Offer to Supplier

Send to Maritec-Naias Lab

Place the sample into the flyer pouch with the following documents:

- Sample Witnessing Form
- Chief Engineer Form
- Bunker Delivery Note/Receipt
- Commercial invoice (Generated by Online Platform)
- Airway Bill (Generated by Online Platform)
- Material Safety Data Sheet (MSDS) (Generated by Online Platform)



Sample Despatch Arrangement



Website: https://pickup.maritec.com.sg/Default


SNo.	<u>Name</u>	<u>Description</u>	<u>Address</u>	Email Ids	Phone Numbers	Mobile Numbers	Contact Person Details	Collection Arrangement
1	CTI Shanghai Lab		Rm 601, No.1, No.760, Xinjunhuan Rd, Pujiang Town, Shanghai, Minhang, China - CN-201100	samplepickup@maritec.com.sg	+86 13671802679	+86 13671802679	Ms. Alice Chen	Via Email
2		Overseas Samples Collection (Asia, Oceania, Middle East, USA)	192 Pandan Loop, #05-27 Pantech Business Hub, Singapore - SG-128381	samplepickup@maritec.com.sg; admin@maritec.com.sg	+65 62718622	+65 96581805	Ms Ratna Fauzi	Via Pick Up platform
		Sample Collection within Singapore only	192 Pandan Loop, #05-27 Pantech Business Hub, Singapore - SG-128381	samplepickup@maritec.com.sg; admin@maritec.com.sg	+65 62718622	+65 96581805		Via Email Via Whatsapp
3	NAIAS Lab	Overseas Samples Collection (EU, South America, Africa, USA)	lmittou 44, Piraeus, Piraeus, Greece - GR-185 40	samplepickup@maritec.com.sg; info@naiaslabs.com	+30 21 0410 0300	I+hh Uhhx I XIIh	Ms Ratna Fauzi Ms Vassia Dailani	Via Pick Up platform
		Sample Collection within Greece only	Imittou 44, Piraeus, Piraeus, Greece - GR-185 40	info@naiaslabs.com	+30 21 0410 0300	+65 96581805	Ms Vassia Dailani	Via Email
4	Indonesia	Sample Collection within Indonesia only	Jl. Raya Pejuangan, Ruko Plaza Kebon Jeruk, Blok E no. 12A Jakarta Barat, Indonesia - ID-11530	Indonesia@maritec.com.sg	+62 818174377	+62 818174377	Ms. Juliana W. Tanudjaja	Via Email







% https://pickup.maritec.com.sg/Default











Click here to New Registration \ Signup

New User to click on New Registration/ Sign Up

Copyright © 2025 MARITEC PTE LTD. All rights reserved. | Privacy | PDPA







Maritec Sample Pickup System



Company Name :*	User Registration	Maritec Client Code:	
Company Name		Enter the Client Code	
First Name :*	Middle Name :	Last Name :	
First Name	Middle Name	Last Name	
Address 1:*	Address 2:	Address 3:	 Complete th
Address 1	Address 2	Address 3	registration (
Select Country :*	Select State / Province / County:*	Select City / District:*	necessary fie
Select Country	~		and submit
Postal Code \ Pincode \ Zipcode:	Mobile:*	Email Id:*	The email ar
Pin Code / Zipcode	+ PC -! Number	Enter your Email ID	password car
			used for futu
Password:*	Confirm Password:**		login
Password	Confirm Password		
Note*: Please fill all required (*) fields before submitti	ing the form.		
Note . Frease in an required () helds before submitted	ing the form.		
	Submit Reset		








% https://pickup.maritec.com.sg/Default











Don't have an account?.

Click here to New Registration \ Signup


Copyright © 2025 MARITEC PTE LTD. All rights reserved. | Privacy | PDPA

























Pac	Package Package Package - 1		No of Fuel Oil Samples		Remove Package (-) Remove		Depending on the number of samples updated, the number of package will be shown below. However, you can remove the additional
Note*	': Please fill all required	(*) fields before submitting the form.				7	package based on the number of packages to courier
			Submit Reset	Finally, click Submit			1 package = 1 Waybill

If submission is successful, there will be notification on successful submission and an email from noreply@maritec.com.sg will send a confirmation email together with the Waybill, Commercial Invoice, MSDS and other necessary documents as required by the shipper's country.

If submission is **not successful**, there will be a notification on the error. Commonly,

- 1. Wrong data entry (please only use alphanumeric only for all the information.)
- 2. The pick up date is not available. Thus, please choose another date. (Monday to Friday only)
- 3. If still unable to rectify the issue, please contact us via whatsapp and we will assist accordingly.









































THANK YOU

Maritec-Naias (A member of CTI Group)

Fuel Solutions and Environmental services provider

E-mail: admin@maritec.com.sg | info@naiaslabs.com

Website: www.maritec.com.sg | www.naiaslabs.com